

SERVICE MANUAL

SRP-275

IMPACT PRINTER



All specifications are subjected to change without notice

Table of contents

Precautions

Safety precautions	i
Servicing Precautions	ii
Precautions for electrostatically sensitive devices (ESDs)	ii

Introduction

iii

Table of contents

v

Chapter 1 Specifications

1.1	General specifications	1-1
1.2	Appearance	1-2
1.2.1	Printer dimensions(mm) and Weight	1-2
1.2.2	AC adapter dimensions (mm)	1-2
1.2.3	Feature locations	1-3
1.3	Reference information	1-4
1.3.1	Printer mechanism specifications	1-4
1.3.2	Printing specifications	1-4
1.3.3	Character specifications	1-5
1.3.4	Paper specifications	1-7
1.3.5	Ribbon cassette specifications	1-8
1.3.6	Environment conditions	1-8
1.3.7	Reliability	1-9
1.3.8	Certification	1-9
1.3.9	Printer(SMP715) pin descriptions	1-10
1.3.10	Printer head specifications	1-11
1.3.11	Printer head thermistor specifications	1-11
1.3.12	PF(Paper Feed) motor specifications	1-12
1.3.13	HF(Head Feed) motor specifications	1-12
1.3.14	Auto cutter specifications	1-12
1.3.15	Switch(Sensor) specifications	1-12
1.4	SMPS(AC adaptor) specifications	1-13
1.4.1	SMPS (Switching Mode Power Supply) specifications	1-13
1.4.2	SMPS output connector	1-13
1.5	I/F(Interface) specifications	1-14
1.5.1	RS-232C Serial I/F	1-14
1.5.1.1	RS-232C Serial I/F specifications	1-14
1.5.1.2	RS-232C Serial I/F cable	1-14
1.5.1.3	RS-232C Serial I/F cable connection	1-15
1.5.1.4	RS-232C Serial I/F signal descriptions	1-15
1.5.1.5	RS-232C Serial I/F H/W flow control	1-16
1.5.1.6	RS-232C Serial I/F S/W flow control	1-16
1.5.2	IEEE 1284 Parallel I/F	1-16
1.5.2.1	IEEE 1284 Parallel I/F forward mode specifications (Compatibility mode)	1-16
1.5.2.2	IEEE 1284 Parallel I/F reverse mode specifications (Nibble/Byte mode)	1-16
1.5.2.3	IEEE 1284 Parallel I/F signal specifications (Compatibility/ Nibble/ Byte mode)	1-17
1.5.2.4	IEEE 1284 Parallel I/F cable	1-17
1.5.3	USB I/F	1-18
1.5.3.1	USB I/F specifications	1-18
1.5.3.2	USB I/F signal description	1-18
1.5.3.3	USB I/F cable	1-18
1.6	Drawer kick-out specifications	1-19
1.6.1	Drawer kick-out cable	1-19
1.6.2	Drawer kick-out cable connection	1-19

Chapter 2 Installation and operation

2.1	Connection and Installation	2-1
2.1.1	Connecting the AC adaptor	2-1
2.1.2	Connecting the interface cable and drawer kick-out cable	2-1
2.1.3	Installing the ribbon cassette	2-2
2.1.4	Installing the paper roll	2-3
2.1.5	Changing the paper width	2-4
2.1.6	Installing the wall mount (Option)	2-5
2.2	Operation	2-6
2.2.1	Using the operation panel	2-6
2.2.2	ERROR LED blinking pattern	2-7
2.2.3	Self test	2-8
2.2.4	Hexadecimal dumping	2-10
2.3	Setting the switches	2-11
2.3.1	Setting the DIP Switches	2-11
2.3.1.1	DIP Switch setting for Epson(ESC/POS) mode	2-11
2.3.1.2	DIP Switch setting for Citizen(iDP3550) mode	2-12
2.3.1.3	DIP Switch setting for Star(SP500) mode	2-13
2.3.1.4	Changing the DIP Switches setting	2-14
2.3.2	Setting the Memory Switches	2-15
2.3.2.1	Memory Switch setting for Epson(ESC/POS) mode	2-15
2.3.2.2	Memory Switch setting for Star(SP500) mode	2-19

Chapter 3 Mechanism operating principles

3.1	Transport mechanism	3-1
3.1.1	Head feeding system	3-1
3.1.2	Paper feeding system	3-2
3.1.3	Ribbon feeding system	3-3
3.1.4	Color changing system	3-3
3.1.4.1	Ribbon shifting system	3-3
3.2	Printing mechanism	3-4
3.3	Detection mechanism	3-5
3.3.1	Home position detection mechanism	3-5
3.3.2	Paper near end detection mechanism	3-6
3.3.3	Paper end detection mechanism	3-7
3.3.4	Rear cover open detection mechanism	3-7
3.3.5	Auto cutter home position detection mechanism	3-8
3.4	Auto cutter mechanism	3-9
3.5	Easy paper loading mechanism	3-10

Chapter 4 Adjustments

4.1	Maintenance	4-1
4.1.1	Cleaning	4-1
4.1.2	Inspection	4-1
4.2	Lubricants and adhesive application	4-2
4.2.1	Lubricant requirements	4-2
4.2.2	Lubricant types	4-2
4.2.3	Lubrication points	4-2
4.2.4	Adhesive application requirements	4-3
4.2.5	Adhesive types	4-3
4.2.6	Adhesive application requirements	4-3
4.3	Tools, lubricants and adhesives	4-3
4.3.1	List of tools	4-3
4.3.2	List of lubricants and adhesives	4-3
4.4	Adjustments	4-4

Table of contents

Chapter 5 Troubleshooting

5.1	Troubleshooting flow chart	5-1
A.	POWER LED does not light	5-2
B.	PAPER LED is lit	5-3
C.	ERROR LED is blink	5-4
D.	ERROR LED is lit	5-5
E.	Self test is not normal	5-6
F.	Data from host is not printed normally	5-7
5.2	Troubleshooting tables	5-8
5.2.1	Initialization problems	5-9
5.2.2	Printing quality problems	5-11
5.2.3	Printer mechanism problems	5-12
5.2.4	Auto cut mechanism problems	5-13

Chapter 6 Disassembly and assembly

6.1	Disassembly	6-1
6.2	SMP715 Printer mechanism unit assembly	6-1
6.2.1	SMP715 Printer mechanism unit component parts	6-1
6.2.2	SMP715 Printer mechanism unit Sub-assembly	6-5
6.2.3	SMP715 Printer mechanism unit Main-assembly	6-14
6.3	Auto cutter unit assembly	6-20
6.3.1	Auto cutter unit component parts	6-20
6.3.2	Auto cutter unit Sub-assembly	6-21
6.3.3	Auto cutter unit Main-assembly	6-24
6.4	SRP-275 Whole unit assembly	6-25
6.4.1	SRP-275 Whole unit component parts	6-25
6.4.2	SRP-275 Whole unit Sub-assembly	6-27
6.4.3	SRP-275 Whole unit Main-assembly	6-33

Chapter 7 Exploded view and parts list

7.1	SMP715A Printer mechanism unit exploded view and parts list	7-1
7.1.1	SMP715A Printer mechanism unit exploded view	7-1
7.1.2	SMP715A Printer mechanism unit parts list	7-3
7.2	SMP715C Printer mechanism unit exploded view and parts list	7-5
7.2.1	SMP715C Printer mechanism unit exploded view	7-5
7.2.2	SMP715C Printer mechanism unit parts list	7-7
7.3	Auto cutter unit exploded view and parts list	7-9
7.3.1	Auto cutter unit exploded view	7-9
7.3.2	Auto cutter unit parts list	7-10
7.4	SRP-275A Whole unit exploded view and parts list	7-11
7.4.1	SRP-275A Whole unit exploded view	7-11
7.4.2	SRP-275A Whole unit parts list	7-13
7.5	SRP-275C Whole unit exploded view and parts list	7-15
7.5.1	SRP-275C Whole unit exploded view	7-15
7.5.2	SRP-275C Whole unit parts list	7-17

Chapter 8 Control commands list

8.1	Command notation	8-1
8.2	Explanation of terms	8-1
8.3	Explanation processing	8-2
8.4	Commands for SRP-275 Series	8-3
8.4.1	Commands list for Epson mode (TM-U220)	8-3
8.4.2	Commands description for Epson mode (TM-U220)	8-4
8.4.3	Commands list for STAR mode (SP500)	8-48
8.4.4	Commands description for STAR mode (SP500)	8-50
8.4.5	Commands list for CITIZEN mode (iDP3550/3551)	8-77
8.4.6	Commands description for CITIZEN mode (iDP3550/3551)	8-78

Chapter 9 Wiring diagram

9.1	Main board wiring diagram	9-1
9.2	Connector sub PCB wiring diagram	9-2
9.3	CPU pin function	9-3
9.4	I/F connector pin (J6)	9-6

Chapter 10 Block diagram**Chapter 11 PCB layout and parts list**

11.1	Main PCB	11-1
11.1.1	Main PCB layout	11-1
11.1.2	Main PCB parts list	11-3
11.2	Connector sub PCB	11-5
11.2.1	Connector sub PCB layout	11-5
11.2.2	Connector sub PCB parts list	11-5
11.3	Operation panel PCB	11-6
11.3.1	Operation panel PCB layout	11-6
11.3.2	Operation panel PCB parts list	11-6
11.4	Head PCB	
11.4.1	Head PCB layout	11-7
11.4.2	Head PCB parts list	11-7
11.5	RS-232C serial I/F PCB	11-8
11.5.1	RS-232C Serial I/F PCB layout	11-8
11.5.2	RS-232C Serial I/F PCB parts list	11-8
11.6	IEEE 1284 parallel I/F PCB	11-9
11.6.1	IEEE 1284 parallel I/F PCB layout	11-9
11.6.2	IEEE 1284 parallel I/F PCB parts list	11-9
11.7	USB I/F PCB	11-10
11.7.1	USB I/F PCB layout	11-10
11.7.2	USB I/F PCB parts list	11-10

Chapter 12 Schematic diagrams

12.1	Main circuit diagrams	12-1
12.2	Head circuit diagram	12-10
12.3	RS-232C Serial I/F circuit diagram	12-11
12.4	IEEE 1284 Parallel I/F circuit diagram	12-12
12.5	USB I/F circuit diagram	12-13

Appendix A Code Tables

A.1	Page 0 (PC437 : USA, Standard Europe (International Character Set : USA))	A-1
A.2	Page 1 (Katakana)	A-2
A.3	Page 2 (PC850 : Multilingual)	A-3
A.4	Page 3 (PC860 : Portuguese)	A-4
A.5	Page 4 (PC863 : Canadian-French)	A-5
A.6	Page 5 (PC865 : Nordic)	A-6
A.7	Page 16 (WPC1252 : Latin1)	A-7
A.8	Page 17 (PC866 : Russian)	A-8
A.9	Page 18 (PC852 : Latin2)	A-9
A.10	Page 19 (PC858 : Euro)	A-10
A.11	Page 21 (PC862 : Israel)	A-11
A.12	Page 22 (PC864 : Arabic)	A-12
A.13	Page 23 (Thai character code 42)	A-13
A.14	Page 24 (WPC1253 : Greek)	A-14
A.15	Page 25 (WPC1254 : Turkish)	A-15
A.16	Page 26 (WPC1257 : Baltic)	A-16
A.17	Page 27 (Farsi)	A-17
A.18	Page 28 (WPC1251 : Russian)	A-18
A.19	Page 29 (PC737 : Greek)	A-19
A.20	Page 30 (PC775 : Baltic)	A-20
A.21	Page 31 (Thai character code 16)	A-21
A.22	Page 32 (OldCode : Israel)	A-22
A.23	Page 33 (WPC1255 : Israel)	A-23
A.24	Page 34 (Thai character code 11)	A-24
A.25	Page 35 (Thai character code 18)	A-25
A.26	International character code table	A-26

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*