

REV : 01
JANUARY 7, 1999

CS SERIES

SERVICE MANUAL

C A S CORPORATION

THE CONTENTS

CHAPTER-I THE GENERAL INTRODUCTIONS

A.... PREFACE	4
B.... THE PRECAUTIONS	4
C.... THE SPECIFICATIONS	4
D.... SEALING METHOD	5

CHAPTER-II THE CALIBRATIONS

A.... GENERAL SPAN CALIBRATION	6
A.1.. SET TO THE CALIBRATION MODE	6
A.2.. THE SPAN CALIBRATION	7
A.3.. TO CHECK THE INITIAL ZERO POINT AND SPAN VALUE	7
A.4.. TO CONFIRM THE SPAN AND TO DO FINE TRIMMING	7
A.5.. RETURN TO THE NORMAL MODE	7
B.... HOW TO SET THE NON-LINEARITY	8
B.1.. SET TO THE CALIBRATION MODE	8
B.2.. THE SPAN CALIBRATION	8
B.3.. TO ADJUST SPAN VALUE	8
B.4.. TO ADJUST MIDDLE VALUE	8
B.5.. RETURN TO THE NORMAL MODE	8

CHAPTER-III THE PART REPLACEMENTS

A.... REPLACEMENT OF THE LOAD CELL	9
A.1.. REPLACEMENT OF THE LOAD CELL	9
A.2.. CORRECTION OF THE ECCENTRICITY	9
A.3.. THE SPAN CALIBRATION	9
B.... REPLACEMENT OF THE ANALOG MODULE	10
B.1.. REPLACEMENT OF THE ANALOG MODULE	10
C.... REPLACEMENT OF THE DIGITAL MODULE	10
C.1.. REPLACEMENT OF THE DIGITAL MODULE	10
D.... REPLACEMENT OF THE KEY BOARD	10
D.1.. REPLACEMENT OF THE KEY BOARD	10
D.2.. TEST THE KEYBOARD	10
D.3.. RETURN TO THE NORMAL MODE	10

CHAPTER-IV THE TRANSFORMER

A.... THE TRANSFORMER	11
-----------------------------	----

CHAPTER-V THE SCHEMATICS

A.... MAIN CIRCUIT DIAGRAM	12
B.... DISPLAY CIRCUIT DIAGRAM	13
C.... DIGITAL MODULE DIAGRAM	14

CHAPTER-VI THE OTHERS

A.... FOR THE SERIAL INTERFACE	15
A.1.. THE COMMUNICATION AGREEMENTS	15
A.2.. THE WIRE CONNECTIONS	15
A.3.. THE PROTOCOL	16
A.4.. THE DATA TRAINS	16
B.... EXPLODED VIEW	18
C.... FULL PARTS LIST	20

APPENDIX - DEVICE SPECIFICATION

* CPU (B0C52/B0C32)	25
* MDS INTEGRATED CIRCUIT (μ PD16310)	29
* RESET I.C (H6052)	39
* EEPROM (AT24C164)	43

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*