



# **DB-II(LCD) SERVICE MANUAL**

(DBB)

## < Table of Contents >

1. Introductions .....	3
1.1. The Preface .....	3
1.2. Precautions .....	3
1.3. Specifications .....	4
1.4. Sealing Method.....	5
2. Calibration Mode.....	6
2.1 How to Go to Normal mode(C - 0) .....	7
2.2 How to Confirm Span Calibrated A/D Value(C - 1) .....	7
2.3 Key Test (C - 2).....	8
2.4 Span Calibration(C - 3).....	8
2.5 Capacity Display and Option Setting(C - 4).....	8
2.5.1 Save Setting(C-4-1).....	8
2.5.2 Capacity Setting(C-4-2).....	9
2.5.3 Save Setting(C-4-3) .....	10
2.5.4 Save Setting(C-4-6) .....	10
2.6 How to Confirm Real A/D value(C - 5) .....	11
2.7 How to Confirm Averaging A/D value(C - 6) .....	11
2.8 % Calibration(C - 7).....	11
2.9 Gravity Constant(C - 9).....	12
2.10 Linearity Compensation(C - 10).....	12
3 The Schematics and Diagram.....	13
3.1 System Block Diagram .....	13
3.2 Circuit Diagram.....	14
3.3 Wiring Diagram.....	16
3.4 Block diagram software.....	167
3.5 Part Location.....	20
3.6 Exploded View .....	22
4 Error Message.....	23
5 Serial Interface.....	25
6 Parts List.....	25

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/CAS/DB-II LCD DBB service and calibration man>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)