



# DS-980

## SERVICE MANUAL

---

**SHANGHAI TERAOKA ELECTRONIC CO., LTD.** --- Technical Support Dept.

1<sup>st</sup> Floor of 2# Building, Jia Yuan Business Center, 51# Long Wu Road, Shanghai China 200020

Tel: +86-21-6408-5151

Fax: +86-21-5490-1934

E-mail: [steservice@digi-scale.com](mailto:steservice@digi-scale.com)

# TABLE OF CONTENT

## ● Important Information

<b>1. General.....</b>	<b>1</b>
1.1 General Layout.....	1
1.2 Purpose.....	1
1.3 Features.....	1
1.4 Operating Conditions.....	2
1.5 Analogy Specifications.....	2
1.6 Capacity/Minimum Graduation/Tare Range.....	2
<b>2. Overview.....</b>	<b>3</b>
2.1 Dimensions.....	3
2.2 Panel Layout.....	3
2.3 Key Functions.....	3
2.4 External Connectors.....	3
2.5 Main Components.....	3
2.6 Existing parts to be used.....	3
<b>3. Maintenance.....</b>	<b>5</b>
3.1 Key functions in maintenance mode.....	5
3.2 SPAN Adjustment.....	5
3.3 Escape From maintenance mode.....	5
3.4 Software ID code& SPAN Switch State check.....	6
3.5 Internal count&A/D count display.....	6
3.6 Specification setting.....	6
3.7 SPEC List.....	7
<b>4. Operation.....</b>	<b>10</b>
4.1 Operation in Weighing Mode.....	10
<b>5. Error Information.....</b>	<b>11</b>
<b>6. RS-232C Interface.....</b>	<b>12</b>
6.1 Specification.....	12
6.2 Pin Assignment.....	12
6.3 Control code and characters.....	12
6.4 Standard type.....	13
6.5 Communication method.....	14
6.6 QUQA TRADING type.....	16
6.7 IBM, HUGIN type.....	17
6.8 ICL type.....	18

6.9 CAS Interface type.....	22
6.10 CAS (PORTUGAL) type.....	25
6.11 NIXDORF type.....	26
6.12 NCR type.....	28
6.13 MONS type.....	29
6.14 SHARPTK300, UP700 type.....	30
6.15 DATECS MP50/500 type.....	33
6.16 NCI4000 type.....	35
<b>7. Disassembling.....</b>	<b>36</b>
7.1 Disassembling of base.....	36
7.2 Disassembling of Indicator Block.....	36
<b>8. Wire &amp; Connection.....</b>	<b>37</b>
8.1 RS232 D067.....	37
8.2 D069 A/D.....	38
8.3 DC JACK.....	39
<b>9. Electrical Diagram.....</b>	<b>40</b>
9.1 Block Diagram of Electrical Connection.....	40
9.2 Physical layout of Electrical Connection.....	41

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : the biggest supplier of cash register and scale manuals on the net