

Service Manual

Contents

Chapter 1. Product Overview	3
1.1 Product Overview.....	3
1.2 Standard Specifications	3
1.3 Appearance.....	5
1.4 Operation Panel	6
1.5 Outer Dimensions	8
Chapter 2 Test Mode	9
2.1 Test Mode Flow.....	9
2.2 Starting Test Mode.....	10
2.3 Ending Test Mode	10
2.4 Memory Switch.....	11
2.5 C1 Mode – Country No. Setting	11
2.5.1 Country No. Table.....	11
2.5.2 Operation.....	12
2.6 C2 Mode – Scale No. and Decimal Point Setting.....	12
2.6.1 Scale No.[X1] Table	12
2.6.2 Decimal Point Indication [X2] Table	12
2.6.3 Operation.....	13
2.7 C3 Mode – Span Adjustment	14
2.7.1 Operation.....	14
2.8 F Mode – Setting Measuring Conditions and E2ROM Clear.....	15
2.8.1 Operation.....	15
2.8.2 Error No. List	16
Chapter 3 Hardware Configuration	17
3.1 Mechanisms	17
3.1.1 Dual Display	17
3.1.2 Single Display.....	19
3.2 Electric Concerns	21
3.2.1 Block Diagram	21
3.2.2 Main Board PS-021	22
3.2.3 Switch Board PS-022	24
3.2.4 Dual Display Board PS-023	24
3.2.5 Connection Board PS-019	24
Chapter 4 Maintenance	25
4.1 Disassembly Procedure	25
4.1.1 Case Disassembly Procedure & Assembly Procedure	25
4.1.2 Main Board (PS-021) Replacement.....	27
4.1.3 Switch Board (PS-022) Replacement.....	27
4.1.4 Customer Display Board (PS-023) Replacement	28
4.1.5 Load Cell Replacement	28
4.1.6 Airproof Rubber Ring Replacement.....	31
4.2 Troubleshooting	32

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/ishida/IPC-WP service manual.html>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

<HTTPS://THE-CHECKOUT-TECH.COM>