



Ohaus Corporation
29 Hanover Road
Florham Park, NJ
07932-0900

INSTRUCTION MANUAL

Model CD-11 Indicator



TABLE OF CONTENTS

OVERVIEW OF CONTROLS AND INDICATOR FUNCTIONS	6
1. GETTING TO KNOW YOUR INDICATOR	7
1.1 Introduction	7
2. INSTALLATION	7
2.1 Unpacking and Checking	7
2.2 Selecting the Location	8
2.3 Connecting the Indicator to a Scale Base	8
2.4 Cautionary Notes	9
2.5 Connecting Power	9
2.5.1 AC Adapter	9
2.5.2 Battery Installation	9
2.5.3 Operating the Indicator	9
2.6 Setup Protection	9
2.7 Initial Setup	10
2.7.1 Control Functions	10
2.7.2 Menu Structure	10
2.7.3 Load Cell Capacity Information	11
2.7.4 Setup Menu	12
2.7.5 Readout Menu	13
2.7.6 Print menu	16
2.7.7 Lockout Switch Menu	17
2.7.8 Connecting the RS232 Interface	18
3. CALIBRATION AND SEALING	19
3.1 Legal for Trade (LFT) Operation and LFT Sealing	20
4. OPERATION	21
4.1 Turning On Indicator	21
4.2 Turning Off Indicator	21
4.3 Zero Operation	21
4.4 Tare Operation	21
4.5 Gross/Net/Tare Recall Operation	22

TABLE OF CONTENTS (Cont.)

4.6 Clear Tare Operation	22
4.7 Unit Switch Operation	22
4.8 Parts Counting Operation	23
4.9 Establishing a New Average Piece Weight	23
4.10 Returning to a Weighing Mode	24
4.11 Returning to a Preset APW	24
4.12 RS232 Commands	25
4.12.1 Output Formats	25
4.13 Printing Data	25
 5. CARE AND MAINTENANCE	26
5.1 Troubleshooting	26
5.2 Error Codes List	27
5.3 Service Information	27
5.4 Replacement Parts	27
5.5 Accessories	27
5.6 Technical Data	27

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/ohaus/CD-11 user manual.html](https://the-checkout-tech.com/manuals/ohaus/CD-11%20user%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)