



Ohaus Corporation
29 Hanover Road
Florham Park, NJ
07932-0900

INSTRUCTION MANUAL

Navigator™ Balances




TABLE OF CONTENTS

OVERVIEW OF CONTROLS	6
OVERVIEW OF DISPLAY INDICATORS	7
1. GETTING TO KNOW YOUR BALANCE	8
1.1 Introduction	8
2. INSTALLATION	8
2.1 Unpacking and Checking the Standard Equipment	8
2.2 Selecting the Location	9
2.3 Installing Wind Shield	9
2.4 Installing Subplatform and Pan	9
2.5 Connecting Power and Communications	10
2.6 Leveling the Balance	10
3. OPERATING YOUR BALANCE	11
3.1 The Menu (Basic Settings of the Instrument)	11
3.2 Turning On the Balance	12
3.3 Calibration	12
3.3.1 Internal Calibration (InCal™)	14
3.3.2 Calibration message	15
3.3.3 Calibration Adjust	16
3.3.4 Span Calibration	17
3.3.5 User Calibration	18
3.3.6 Linearity Calibration	19
3.3.7 Calibration Test	20
3.3.8 Calibration GLP Printout	21
3.4 Weighing	22
3.5 Percent Weighing	23
3.6 Parts Counting	24
3.7 Animal Weighing	25
3.8 Checkweighing	26
3.9 Printing Data	27
4. SETTING UP YOUR BALANCE	28
4.1 Setting Date and Time	28
4.2 Readout	29

TABLE OF CONTENTS (Cont.)

4.3 Good Laboratory Practices (GLP) Data	30
4.4 Good Laboratory Practices (GLP) Set	30
4.5 Print	31
4.6 RS232	33
4.7 Mode	34
4.8 Units	35
4.9 Global	35
4.10 Custom Unit	37
4.11 Auto Shut-Off	39
4.12 Menu Lock-Out Protection	40
4.13 Weigh Below	40
5. CARE AND MAINTENANCE	41
5.1 Troubleshooting	41
5.2 RS232 Interface	42
5.3 Error Codes List	45
5.4 Information Messages	45
5.5 Service Information	46
5.6 Replacement Parts	46
5.7 Accessories	47
5.8 Specifications	47

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*