

AVERY
WEIGHTRONIX
AWB
series Indicator
Scales

AVERY
AWB 120
AWB 300

Table of Contents

SECTION 1 INTRODUCTION.....	1
SECTION 2 SPECIFICATIONS.....	2
SECTION 3 INSTALLATION.....	3
3. 1 General installation.....	3
3. 2 Installation of AVERY AWB series.....	3
3. 3 Port connect.....	4
3.3.1 Port location.....	4
3.3.2 Load cell port.....	5
3.3.3 RS-232.....	5
3.3.4 Analog output and check weighing output.....	5
3.3.5 Mercury level bubble.....	6
SECTION 4 KEY DESCRIPTIONS.....	7
SECTION 5 DISPLAY.....	8
SECTION 6 OPERATION.....	9
6.1 Zeroing the display.....	9
6.2 Taring.....	9
6.3 Weighing a sample.....	9
6.4 Check-weighing.....	9
6.4.1 About check weighing.....	9
6.4.2 Set limit.....	10
6.4.3 Set check weighing mode.....	10
6.4.4 Note.....	10
6.5 Accumulated total.....	10
6.5.1 Note.....	10
6.5.2 Accumulate operate.....	10
6.5.3 Memory recall.....	11
6.5.4 Memory clear.....	11
6.5.5 Automatically accumulate.....	11
6.6 Animal keyboard lock.....	11 6.7 11 6.8
set auto power off	11
SECTION 7 PARAMETERS.....	12
SECTION 8 BATTERY OPERATION.....	16
SECTION 9 RS-232 OUTPUT.....	17
9.1 basic information.....	17
9.2 normal output.....	17
9.3 continuously output protocol.....	17
SECTION 10 CALIBRATION.....	18
SECTION 11 ERROR CODE.....	20

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Weigh-Tronix/AWB operation service and calibra](https://the-checkout-tech.com/manuals/Weigh-Tronix/AWB%20operation%20service%20and%20calibration%20manual.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)