

**Avery Weigh-Tronix**

# **ZM303**

## **Indicator**



## **User Instructions**

# Table of Contents

page

<b>Chapter 1 General information and warnings</b> .....	7
About this manual .....	7
Text conventions .....	7
Special messages .....	7
Installation .....	7
Safe handling of equipment with batteries .....	8
Wet conditions .....	8
Routine maintenance .....	8
Cleaning the machine .....	9
Training .....	9
Sharp objects .....	9
FCC and EMC declarations of compliance .....	9
United States .....	9
Canada .....	9
European Countries .....	9
Declarations of conformity .....	10
<b>Chapter 2 Introduction</b> .....	12
Front panel .....	13
Annunciators .....	14
Powering up the ZM303 .....	15
Entering a negative number .....	15
<b>Chapter 3 Indicator applications</b> .....	16
General weighing application .....	16
SELECT key default function .....	16
Gross weighing .....	16
Net weighing .....	17
Using Pushbutton Tare .....	17
Using Entered Tare .....	18
Using Preset Tare .....	18
Using setpoints .....	19
Printing .....	20
Accumulator application .....	21
SELECT key default function .....	21
Special key functions .....	21
Accumulator operation .....	21
Counting application .....	22
SELECT key default function .....	22
Special key functions .....	22
Sample operation .....	22
Dribble sampling .....	22
Bulk sampling .....	23
Piece weight entry .....	24
Checkweighing application .....	25
SELECT key default function .....	25
Special key functions .....	25
Checkweigh operation .....	25
Weighing a target object .....	26
Setting upper and lower limits .....	26
Setpoint operation in the checkweighing application .....	27

Batching application .....	28
SELECT key default function .....	28
Special key functions .....	28
Batching operation .....	28
2-Speed filling .....	29
Ingredient filling .....	29
Independent setpoints .....	29
Fill/Discharge .....	30
Peak hold application .....	31
SELECT key default function .....	31
Special key functions .....	31
Peak hold operation .....	31
Remote display application .....	32
<b>Chapter 4 Menus .....</b>	<b>33</b>
Accessing the menus .....	33
Menu annunciators .....	33
Exiting the menus .....	34
USER level menus .....	34
User menu .....	35
Time .....	35
Date .....	36
Site ID .....	37
Seal .....	37
About menu .....	38
Boot .....	38
Firm and App .....	39
Serial .....	39
Option .....	39
Enet .....	40
Dload .....	41
Audit menu .....	42
Counter .....	42
Print .....	43
<b>Chapter 5 Communications .....</b>	<b>44</b>
Default print formats .....	44
<b>Chapter 6 Error messages .....</b>	<b>45</b>
<b>Chapter 7 Supervisor menu .....</b>	<b>46</b>
General Weighing application supervisor menu .....	47
Setpoint .....	48
Annunciators .....	48
Outputs .....	48
Inputs .....	49
Print .....	49
Reset .....	50
Tare .....	50
Tare Register 1-10 .....	50
Printing .....	51
Reset .....	51
Battery .....	51
Enable .....	52
Timeout .....	52
Accumulator application supervisor menu .....	53
Accumulator .....	54
Print total .....	54

Total format .....	54
Clear total .....	55
Print .....	55
Reset .....	55
Counting application supervisor menu .....	57
Count .....	58
Mode .....	58
Print total .....	58
Total format .....	59
Clear total .....	59
Checkweighing application supervisor menu .....	61
Check .....	62
Outputs - Latch & Unlatch .....	62
Under divisions .....	62
Over divisions .....	63
Reset .....	63
Batching application supervisor menu .....	64
Batch .....	64
Type .....	65
Mode .....	65
Display .....	66
Preact .....	66
Negative fill .....	67
Notes on batching .....	67
2 Speed .....	67
Ingredient .....	68
Independent Setpoints .....	68
Fill/Discharge .....	68
Peak Hold application supervisor menu .....	69
Peak hold .....	69
Reset .....	70
Remote Display application supervisor menu .....	71

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*